## **UTC-1 - UTC Controller**



The UTC (Up the Coax) Controller is used with the GENESIS-3s series of cameras to switch between HDCVI, HDTVI, AHD & CVBS video formats to suit the requirement of the recorder on site. This is beneficial when the current video format of the camera is not compatible with the recorder.

The part number on the ERP system is "UTC-1"

## Features:

In-line Controller - The device plugs in between the camera & the coax cable, meaning you can configure your cameras & then disconnect it. It can be used at either the camera end or recorder end of the cable.

Indicator light – The controller's LED light will indicate the current video format.

| HDCVI   | Orange |
|---------|--------|
| HDTVI   | Green  |
| AHD     | Blue   |
| CVBS/SD | Red    |

## **Operation:**

- Step 1 Press the 'Enter' button to wake the controller, the 4 indicator lights will flash once. The controller will then detect & indicate the current video format
  - Step 2 Hold down the button of desired format for 10 seconds. You will then see the format on screen change & the controller's LED will indicate the new format.